

Connecting to and Viewing on TV


Images are projected horizontally on the TV.

- Adjust the TV's screen accordingly.


By connecting the supplied AV cable to the video terminal, videos can be played back on a TV.

- Refer also to the instruction manual of the TV in use.


1 Connect the AC adapter to this unit.




2 Open the LCD monitor and select the playback mode.



3 Connect to the TV.



4 Press the external input button on the TV to switch to the input from this unit via the connected terminal.



5 Play back a file.



- Memo:**
- To play back with date/time display, set “DISPLAY ON TV” in the connection settings menu to “ON”. Set “ON-SCREEN DISPLAY” in the playback menu to “DISPLAY ALL” or “DISPLAY DATE ONLY”.
  - For questions about the TV or method of connection, contact your TV's manufacturer.

Unnatural Displays on TV

Trouble	Action
Images do not appear on the TV properly.	<ul style="list-style-type: none"><li>Disconnect the cable and connect again.</li><li>Turn off and on this unit again.</li></ul>
Images are projected vertically on the TV.	<ul style="list-style-type: none"><li>Set “VIDEO OUTPUT” in the connection settings menu to “4:3”.</li></ul>