


Manual Recording


You can adjust settings, such as brightness and shutter speed, by using the manual mode.

1 Select the Manual recording mode.



- The mode changes between Auto and Manual with every press.

2 Start recording.



- Press again to stop.

Memo:

- The manual settings are displayed only in the manual mode.

Manual Recording Menu

The following items can be set.

Name	Description
SCENE SELECT	• Recordings that suit the shooting conditions can be performed easily.
FOCUS	• Use manual focus if the subject is not focused automatically.
BRIGHTNESS ADJUST	• Overall brightness on the screen can be adjusted. • Use this when recording in a dark or bright location.
SHUTTER SPEED	• Shutter speed can be adjusted. • Use this when shooting a fast-moving subject or to emphasize the subject's movement.
WHITE BALANCE	• Overall color on the screen can be adjusted. • Use this when the color on the screen appears differently from the actual color.
BACKLIGHT COMP.	• Corrects the image when the subject appears dark due to backlight. • Use this when shooting against the light.
METERING AREA/TYPE	• Brightness of a specified area can be set as the standard.
TELE MACRO	• Use this to take close-up (macro) shots of the subject.