

Carga de la batería en el extranjero

La forma del tomacorriente varía según el país y la región.
Para cargar la batería, necesita un enchufe adaptador que coincida con la forma del tomacorriente.

A	B	BF	C	O
				

North America		Europe		Oceania		Middle East	
United States	A	Iceland	C	Australia	O	Israel	C
Canada	A	Ireland	C	Guam	A	Iran	C
Mexico	A	United Kingdom	B, BF	Tahiti	C	Kuwait	B, C
Asia		Italy	C	Tonga	O	Jordan	B, BF
India		Austria	C	New Zealand	O	Africa	
Indonesia		Netherlands	C	Fiji	O	Algeria	A, B, BF, C
Singapore		Canary Islands	C	Latin		Egypt	B, BF, C
Sri Lanka		Greece	C	Argentina	O	Guinea	C
Thailand		Switzerland	C	Colombia	A	Kenya	B, C
South Korea		Sweden	C	Jamaica	A	Zambia	B, BF
China		Spain	A, C	Chile	B, C	Tanzania	B, BF
Japan		Denmark	C	Haiti	A	Republic of South Africa	
Nepal		Germany	C	Panama	A		B, C, BF
Pakistan		Norway	C	Bahamas	A	Mozambique	C
Bangladesh		Hungary	C	Puerto Rico	A	Morocco	C
Philippines		Finland	C	Brazil	A, C		
Vietnam		France	C	Venezuela	A		
Hong Kong Special		Belgium	C	Peru	A, C		
Administrative Region		Poland	B, C				
Macau Special		Portugal	B, C				
Administrative Region		Romania	C				
Malaysia							