


**LIGHT (GZ-MS250/GZ-MS240/GZ-MS230)**


Turns on/off the light.


| Setting | Details                                               |
|---------|-------------------------------------------------------|
| OFF     | Does not light up.                                    |
| AUTO    | Lights up automatically when the surrounding is dark. |
| ON      | Lights up at all times.                               |

**Displaying the Item**

1 Select still image mode.



2 Touch  to display the menu.



3 Select "LIGHT" and touch .

