DEMO MODE

Starts playback of the demo mode which introduces the features of this unit

Setting	Details
OFF	Deactivates the function.
ON	Plays a demonstration of the special features of this unit.

Displaying Demo Mode

- ① Remove the battery pack and SD card.
- ② Connect the AC adapter.
- 3 Open the LCD monitor and turn on the power.
- Demonstration starts playing after 3 minutes.
- To stop playback, touch .

NOTE:

• This mode is not available in the playback mode.

Displaying the Item

 ${\it 1}$ Touch $\ensuremath{ ext{@}}$ to display the menu.



2 Select "BASIC SETTINGS" and touch ®.



 $\it 3$ Select "DEMO MODE" and touch \odot .

