LIGHT (GZ-MS250/GZ-MS240/GZ-MS230)

Turns on/off the light.

	Setting	Details
	OFF	Does not light up.
	AUTO	Lights up automatically when the surrounding is dark.
	ON	Lights up at all times.

Displaying the Item

1 Select video mode.



 $2\,$ Touch $\ensuremath{\textcircled{\tiny m}}$ to display the menu.



 ${\it 3}$ Select "LIGHT" and touch ${\it ©}$.

