

## Manual Settings Menu

Recording settings can be adjusted manually.

**NOTE:**

- They are displayed only when recording in the manual mode.

Setting	Details
SCENE SELECT	Settings to suit the shooting condition can be selected. "Scene Selection" ( P. 0 )
FOCUS	Focus can be adjusted manually. "Adjusting Focus Manually" ( P. 0 )
BRIGHTNESS ADJUST	Adjusts the overall brightness of the screen. "Adjusting Brightness" ( P. 0 )
SHUTTER SPEED	Shutter speed can be adjusted. "Setting Shutter Speed" ( P. 0 )
WHITE BALANCE	Adjusts the color according to the light source. "Setting White Balance" ( P. 0 )
BACKLIGHT COMP.	Corrects the image when the subject appears dark due to backlight. "Setting Backlight Compensation" ( P. 0 )
METERING AREA/ TYPE	Enables you to adjust the brightness in the desired area. "Setting Metering Area" ( P. 0 )
EFFECT	Records videos or still images with special effects such as sepia or black and white. "Recording with Effects (GZ-MS250/GZ-MS240/GZ-MS230)" ( P. 0 )
TELE MACRO	Enables close-up shots when using the telephoto (T) end of the zoom. "Taking Close-up Shots" ( P. 0 )