

Playback Menu (Video)

You can delete or look for specific videos.

Setting	Details
DELETE	Deletes unwanted videos. "Deleting the Currently Displayed File" (P. 0) "Deleting Selected Files" (P. 0) "Deleting All Files" (P. 0)
SEARCH	Refines the index screen of videos according to group, recording date, or event. "Group Search" (P. 0) "Date Search" (P. 0) "Event and Date Search" (P. 0)
PLAYBACK PLAYLIST	Play back the playlists that you have created. "Playing Back Playlists" (P. 0)
EDIT PLAYLIST	Creates or edits a playlist. "Creating Playlists with Selected Files" (P. 0) "Creating Playlists by Group" (P. 0) "Creating Playlists by Date" (P. 0) "Creating Playlists by Event" (P. 0) "Editing Playlists" (P. 0) "Deleting Playlists" (P. 0)
PLAYBACK MPG FILE	Plays videos with defective management information. "Playing a Video with Defective Management Information" (P. 0)
EDIT	<ul style="list-style-type: none"> • COPY Copies files to another media. "Copying All Files" (P. 0) "Copying Selected Files" (P. 0) • MOVE Moves files to another media. "Moving All Files" (P. 0) "Moving Selected Files" (P. 0) • PROTECT/CANCEL Protects files from being deleted accidentally. "Protecting the Currently Displayed File" (P. 0) "Protecting Selected Files" (P. 0) "Protecting All Files" (P. 0) "Releasing Protection of All Files" (P. 0) • TRIMMING Select the required part of a video and save it as a new video file. "Capturing a Required Part in the Video" (P. 0) • CHANGE EVENT REG. Changes the event that is registered. "Changing the Event of the Currently Displayed File" (P. 0) "Changing the Event of the Selected Files" (P. 0)
ON-SCREEN DISPLAY	Sets whether to show on-screen displays such as icons during playback. "ON-SCREEN DISPLAY" (P. 0)