Basic Settings Menu

You can adjust various camera settings such as operation sound, etc.

| Setting | Details |
|-----------------|--|
| DEMO MODE | Introduces the special features of this unit in digest form. "DEMO MODE" (188 P. 0) |
| AUTO POWER OFF | Prevents the situation of forgetting to turn off the power when this is set. "AUTO POWER OFF" (1878 P. 0) |
| OPERATION SOUND | Turns on or off the operation sound. "OPERATION SOUND" (© P. 0) |
| RECORD BUTTON | Displays the REC button on the LCD monitor and enables it to be used as the START/STOP button. "RECORD BUTTON" (FOR P. 0) |
| QUICK RESTART | Reduces the power consumption within 5 minutes after the LCD monitor is closed to 1/3 of that used during recording. "QUICK RESTART" (IST P. 0) |
| UPDATE | Updates the functions of this unit to the latest version. "UPDATE" (IPP P. 0) |
| FACTORY PRESET | Returns all the settings to their default values. "FACTORY PRESET" (© P. 0) |