NO REGISTERED SCENES IN PLAYLIST SOME SCENES MAY NOT PLAY BACK

Delete the playlist, and then create a new one.
"Creating Playlists from the Recorded Videos" （☞ P. 0 ）