Grip Adjustment

When holding this unit, keep your elbows close to your sides to prevent camera shake.





CAUTION:-

- Be careful not to drop this unit during transportation.
- Guardians should pay close attention when this unit is being used by children.

NOTE:

• If camera shake is excessive, use the digital image stabilizer.

"Reducing Camera Shake" (P. 0)