The remaining battery display is not correct.

Remaining battery power is not displayed when the AC adapter is con-

nected.

If this unit is used for long periods of time in high or low temperatures, or if the battery pack is repeatedly charged, the amount of remaining battery may not be displayed correctly.