

**Verifying System Requirements (Guideline)**

Right-click on “Computer” (or “My Computer”) in the “Start” menu and select “Properties” to check the following items.

**Windows Vista/Windows 7**

- Refer to the operating instructions found in the animation on the Detailed User Guide.

**Windows XP**

- Refer to the operating instructions found in the animation on the Detailed User Guide.

	<b>Windows Vista/Windows 7</b>	<b>Windows XP</b>
OS	Windows Vista Home Basic or Home Premium (Pre-installed versions only)Windows 7 Home Premium(Pre-installed versions on- ly) Service Pack 2 32/64-bit	Windows XP Home Edition or Professional (Pre-installed versions only)Service Pack 3
CPU	Intel Core Duo CPU 1.5 GHz or higher Intel Pentium 4 CPU 1.6 GHz or higher Intel Pentium M CPU 1.4 GHz or higher	Intel Core Duo CPU 1.5 GHz or higher Intel Pentium 4 CPU 1.6 GHz or higher Intel Pentium M CPU 1.4 GHz or higher
RAM	At least 1 GB (1024 MB)	At least 512 MB

**NOTE:**

- If your PC does not meet the above system requirements, operations of the provided software cannot be guaranteed.
- For more information, contact your PC's manufacturer.