

Playback Menu (Still Image)

You can delete or look for specific still images.

Setting	Details
DELETE	Deletes unwanted still images. "Deleting the Currently Displayed File" (P. 0) "Deleting Selected Files" (P. 0) "Deleting All Files" (P. 0)
SEARCH DATE	You can search and play videos or still images according to recording dates. "Date Search" (P. 0)
EDIT	<ul style="list-style-type: none"> ● COPY Copies files to another media. "Copying All Files" (P. 0) "Copying Selected Files" (P. 0) ● MOVE Moves files to another media. "Moving All Files" (P. 0) "Moving Selected Files" (P. 0) ● PROTECT/CANCEL Protects files from being deleted accidentally. "Protecting the Currently Displayed File" (P. 0) "Protecting Selected Files" (P. 0) "Protecting All Files" (P. 0) "Releasing Protection of All Files" (P. 0)
SLIDE SHOW EFFECTS	Effects can be added to the transitions in slideshow playback. "SLIDE SHOW EFFECTS" (P. 0)
ON-SCREEN DISPLAY	Sets whether to show on-screen displays such as icons during playback. "ON-SCREEN DISPLAY" (P. 0)