


**ON-SCREEN DISPLAY**

Sets whether to show on-screen displays such as icons during playback.


Setting	Details
OFF	No display at all.
DISPLAY ALL	Displays everything.
DISPLAY DATE ONLY	Displays the date only.

**Displaying the Item**


1 Select the playback mode.



2 Select video mode.



3 Touch **MENU** to display the menu.



4 Select "ON-SCREEN DISPLAY" and touch **OK**.

