Images are projected vertically on the TV.

Set "VIDEO OUTPUT" in the connection settings menu to "4:3".
"VIDEO OUTPUT" (☞ P. 0)
Adjust the TV's screen accordingly.