
No date/time display.

Set "ON-SCREEN DISPLAY" in the menu accordingly.

"ON-SCREEN DISPLAY" (P. 0)

Set "DISPLAY ON TV" in the menu to "ON".

"DISPLAY ON TV" (P. 0)