

Manual Settings Menu

Recording settings can be adjusted manually.

NOTE:

- They are displayed only when recording in the manual mode.

Setting	Details
SCENE SELECT	Settings to suit the shooting condition can be selected. "Scene Selection" (P. 0)
FOCUS	Focus can be adjusted manually. "Adjusting Focus Manually" (P. 0)
BRIGHTNESS ADJUST	Adjusts the overall brightness of the screen. "Adjusting Brightness" (P. 0)
SHUTTER SPEED	Shutter speed can be adjusted. "Setting Shutter Speed" (P. 0)
WHITE BALANCE	Adjusts the color according to the light source. "Setting White Balance" (P. 0)
BACKLIGHT COMP.	Corrects the image when the subject appears dark due to backlight. "Setting Backlight Compensation" (P. 0)
METERING AREA/ TYPE	Enables you to adjust the brightness in the desired area. "Setting Metering Area" (P. 0)
EFFECT	Records videos or still images with special effects such as sepia or black and white. "Recording with Effects (GZ-MS230)" (P. 0)
TELE MACRO	Enables close-up shots when using the telephoto (T) end of the zoom. "Taking Close-up Shots" (P. 0)