
Cannot find a recorded file.

Cancel group display and date search functions.

"Searching for a Specific Video/Still Image" (P. 0)

Change the setting in "REC MEDIA FOR VIDEO" or "REC MEDIA FOR IMAGE". (Files on other media are not displayed.)

"REC MEDIA FOR VIDEO (GZ-MS230)" (P. 0)

"REC MEDIA FOR IMAGE (GZ-MS230)" (P. 0)

Select "PLAYBACK MPG FILE" then search the video on the index screen. (Video files that have damaged management information can be played back.)

"Playing a Video with Defective Management Information" (P. 0)