## **Scene Selection**

Common scenes that are often encountered can be recorded with the most suitable settings.

1 Touch em to display the menu.



2 Select "MANUAL SETTING" and touch @.



3 Select "SCENE SELECT" and touch @.



4 Select the scene and touch 68.



Setting	Effect
⊠ NIGHT EYE	Increases gain and brightens the scene automatically when the surrounding is dark.  To prevent camera shake, use a tripod.
	OFF
SPOT- LIGHT	Prevents the human subject from appearing too bright under light.  OFF  ON

<sup>\*</sup>The image is only an impression.