
## **Common Recording Indications**



- 1 Recording Mode
- 2 Effect
- 3 Scene Select
- 4 Auto REC
- 5 White Balance
- 6 Quick Review
- **7** Zoom
- 8 Media
- 9 Monitor Backlight
- 10 Metering Area "SPOT" C
- 11 Focus Assist
- 12 Battery Indicator
- 13 Date/Time
- 14 Focus
- 15 Tele Macro
- 16 Backlight Compensation
- D: Face Priority AE/AF
- 17 Brightness
- 18 Shutter Speed