


**Front****1** Lens

- Do not touch the lens and lens cover.
- Do not cover the lens with your fingers during video recording.

**2** Stereo Microphone

- Do not cover the microphone with your fingers during video recording.

**3** Camera Sensor

- Do not cover the sensor with your fingers during video recording.

**4** POWER/CHARGE Lamp

- Lights up: Power "ON"
- Blinks: Charging in progress
- Goes out: Charging finished

**5** ACCESS Lamp

- Recording or playback is in progress when the lamp lights up or blinks.
- Do not remove the battery pack, AC adapter, or SD card.