

---

### **CHECK LENS COVER**

Appears for 5 seconds after power is turned on, if the lens cap is attached or when it is dark.