

Digest Playback

You can play back a few seconds from each scene of the recorded videos in the created DVD.

- 1** Load the created DVD on a DVD player.
- 2** Select "DIGEST PLAYBACK" on the TV.
 - The digest is played back continuously.



(The screen does not appear on this unit.)

Memo:

- To normal playback/To index menu
 - 1) Press the top menu button on the remote control of the DVD device during digest playback.
 - 2) Select the desired item.
 - "DIGEST PLAYBACK" menu is not available when the DVD is created using the provided Everio MediaBrowser software.
-