


Interior



1 Speaker

- Outputs audio sound during video playback.

2 (Play) Button

- Switches between the recording and playback modes.

3 / (Video/Still Image) Button

- Switches between video and still image.

4 UPLOAD/EXPORT* (Upload/Export to iTunes*) Button

- Recording: Takes videos in YouTube™ or iTunes* format.
- Playback: Changes the video to YouTube™ or iTunes* format.
(*GZ-HM330 only)

5 (Power/Info) Button

- Recording: Displays the remaining time (for video only) and battery power.
- Playback: Displays file information such as recording date.
- Press and hold to turn the power on/off while the LCD monitor is opened.

6 AV Terminal

- Connects to a TV.

7 COMPONENT Terminal

- Connects to a TV.

8 HDMI Terminal

- Connects to an HDMI TV.