


Playing Back Files in the USB External Hard Disk Drive


- 1 Select video or still image mode.



- 2 Select "PLAYBACK" and touch **OK**.



- 3 Select the desired folder and touch **OK**.



- 4 Select the desired file and touch **OK**.



- Touch **■** to stop playback.