



Moving Selected Files

Moves selected videos and still images to another media.
Files that are moved will be deleted from the original media.


1 Select the playback mode.



2 Select video or still image mode.



3 Touch MENU to display the menu.



4 Select "EDIT" and touch OK .




5 Select "MOVE" and touch OK .



6 Select the direction of moving and touch OK .

- The direction of moving varies with the model.

7 Select "SELECT AND MOVE" and touch OK .



8 Select the desired file and touch OK .



- A check mark appears on the selected file.
To remove the check mark, touch OK again.

9 After selecting all the files to move, touch EXEC.



10 Select "YES" and touch OK .



- Moving of files starts.
- After moving, touch OK .