
Images do not appear on the TV properly.

Disconnect the cable and connect again.

Turn off and on this unit again.

When connected via the component connector, check if the setting of "COMPONENT OUTPUT" in the connections setting menu is suitable for the connected TV. (Set to "1080i" by default)