

VIDEO QUALITY

Sets the video quality.


Setting	Details
UXP	Enables recording in the best picture quality. <ul style="list-style-type: none"> • Applies to BDs only. To save to DVDs, it is necessary to re-encode the videos to XP mode using the provided software.
XP	Enables recording in high picture quality.
SP	Enables recording in standard quality.
EP	Enables long recordings.

Memo:


- Set to “UXP” or “XP” mode when recording fast-moving scenes or scenes with extreme change of brightness to avoid noise.
- Use a BD writer to save videos recorded in UXP mode.

Displaying the Item

1 Select video mode.



2 Touch to display the menu.



3 Select “VIDEO QUALITY” and touch .

