


VIDEO QUALITY

Sets the video quality.


Setting	Details
UXP	Enables recording in the best picture quality. <ul style="list-style-type: none"> Applies to BDs only. Videos taken in high-definition quality cannot be saved to DVDs.
XP	Enables recording in high picture quality.
SP	Enables recording in standard quality.
EP	Enables long recordings.


Memo:


- Set to UXP or XP mode when recording fast-moving scenes or scenes with extreme change of brightness to avoid noise.
- Use a BD writer to save videos recorded in UXP mode.
- You can change the video quality from the remaining recording time display. Select the video quality with the slider and touch .

Displaying the Item

1 Select video mode.



2 Touch  to display the menu.



3 Select "VIDEO QUALITY" and touch .

