
# **Using the Remote Control**

You can operate this unit from a distance away using the supplied remote control.




### Memo:

- Point the remote control toward the sensor directly and use it within 5 m from this unit.
- The transmitted beam may not be effective or may cause incorrect operation when the sensor is directly exposed to sunlight or powerful lighting.

#### **Preparing the Remote Control**




#### Using the Remote Control for the First Time




 A button battery (CR2025) is included inside the remote control at the time of purchase.
Remove the insulation sheet before use.

## **Reinserting the Battery**



- Pull out the battery holder by pressing the lock tab.
- Insert the button battery with the + side facing upward.

#### **Operation Buttons on Remote Control Unit**



- 1 Recording Start/Stop Button
- Starts/stops video recording.
- 2 Still Image Button
- Takes a still image.
- 3 Zoom Button
- T: Zooms inW: Zooms out
- 4 Basic Playback Operations

Operation Button	Description
Playback/Pause Button ▶ / ▮▮	Starts/pauses playback of videos or slide- shows.
Left Button ◀◀	Moves the cursor to the left. Performs reverse search during playback.
Right Button	Moves the cursor to the right. Performs forward search during playback.
T Button <b>T</b>	Zooms in. (during pause) Turns up (+) the volume during video playback.
W Button W	Zooms out. (during pause) Turns down (-) the volume during video playback.

## 5 Index Button

- $\bullet\,$  Stops playback and returns to thumbnail display.
- 6 Info Button
- Recording: Displays the remaining time (for video only) and battery power.
- Playback: Displays file information such as recording date.