


Connecting via the Component Connector

You can connect this camera to the component terminal of a TV to play back videos in analog high-definition quality.


- Refer also to the instruction manual of the TV in use.

1 Connect to the TV.



- Press and hold the power button for 2 seconds or more to turn off the power.

2 Connect the AC adapter to this unit.



3 Press the external input button on the TV to switch to the input from this unit via the connected terminal.



4 Play back a file.



Memo:

- To play back with date/time display, set "DISPLAY ON TV" in the connection settings menu to "ON". Set "ON-SCREEN DISPLAY" in the playback menu to "DISPLAY ALL" or "DISPLAY DATE ONLY".
- When playing back in HD quality, set "COMPONENT OUTPUT" in the connection settings menu to "1080i".
- The video is output in standard quality if the setting remains at "480i".
- For questions about the TV or method of connection, contact your TV's manufacturer.