


Common Recording Indications



- 1** Recording Mode
- 2** Effect
- 3** Scene Select
- 4** Auto REC
- 5** White Balance
- 6** Zoom
- 7** Media
- 8** GPS Communication Status (GZ-HM550 only)
- 9** Radio Reception Status (GZ-HM550 only)
- 10** Metering Area "SPOT"
- 11** Focus Assist
- 12** Battery Indicator
- 13** Date/Time
- 14** Monitor Backlight
- 15** Focus
- 16** Tele Macro
- 17** Backlight Compensation
- 18** Face Priority AE/AF
- 19** Brightness
- 20** Shutter Speed