## **Moving Selected Files**

Moves selected videos and still images to another media. Files that are moved will be deleted from the original media.

1 Select the playback mode.



2 Select video or still image mode.



3 Touch end to display the menu.



4 Select "EDIT" and touch ®.



5 Select "MOVE" and touch @.



6 Select the direction of moving and touch 68.



7 Select "SELECT AND MOVE" and touch @s.



8 Select the desired file and touch @.



- A check mark appears on the selected file.

  To remove the check mark, touch ® again.
- **9** After selecting all the files to move, touch EXEC.



10 Select "YES" and touch .



- Moving of files starts.
- After moving, touch @.