


DISPLAY ON TV

Displays icons and date/time on a TV screen.


Setting	Details
OFF	Does not display icons and date/time on TV.
ON	Displays icons and date/time on TV.

Displaying the Item

1 Touch  to display the menu.



2 Select “CONNECTION SETTINGS” and touch .



3 Select “DISPLAY ON TV” and touch .

