


## Setting Shutter Speed

You can set the shutter speed to suit the type of subject.

- 1 Touch  to display the menu.



- 2 Select "MANUAL SETTING" and touch .



- 3 Select "SHUTTER SPEED" and touch .



- 4 Select "MANUAL" and touch .



- 5 Select the shutter speed with the slider.



- Shutter speed can be set from 1/2 to 1/4000. (Up to 1/500 for still image.)
- Slide upward to increase the shutter speed.
- Slide downward to decrease the shutter speed.

- 6 Touch  to confirm.



### Memo:

- Settings can be adjusted separately for videos and still images.