

SHUTTER MODE


Continuous shooting settings can be adjusted.

Setting	Details
RECORD ONE SHOT	Records one still image.
CONTINUOUS SHOOTING	Records still images continuously while the SNAPSHOT button is pressed.


- Memo:**
- You can change the continuous shooting speed with CONT. SHOOTING SPEED in the basic settings menu.
  - Some SD cards may not support continuous shooting.
  - The continuous shooting speed will drop if this function is used repeatedly.

Displaying the Item

1 Select still image mode.



2 Touch  to display the menu.



3 Select "SHUTTER MODE" and touch .

