## **Scene Selection**

Common scenes that are often encountered can be recorded with the most suitable settings.

1 Touch (e) to display the menu.



2 Select "MANUAL SETTING" and touch @.



3 Select "SCENE SELECT" and touch @.



4 Select the scene and touch on.



• After setting, touch .

\*The image is only an impression. Setting **Effect NIGHT EYE** Increases gain and brightens the scene automatically using a slow shutter when the surrounding is dark. To prevent camera shake, use a tripod. **OFF** ON NIGHT Captures night scenes naturally. ON **OFF** PORTRAIT Blurs the background to bring out the people in the picture. **OFF** ON **SPORTS** Captures fast-moving subjects clearly in every single frame. **OFF** ON SNOW Prevents the subject from appearing too dark when recording snow scenes on a sunny day. OFF ON **SPOTLIGHT** Prevents the human subject from appearing too bright under light. OFF ON