## Copying Selected Files

Select and copy the desired videos.

1 Select video or still image mode.

2 Select "SELECT AND CREATE" (video) or "SELECT AND SAVE" (still image), and touch ⓀK.

3 Select the media for copying and touch ⓀK.

4 Select "SELECT FROM SCENES" (videos) or "SELECT FROM IMAGES" (still images), and touch ⓀK.

5 Select the video or still image to save, and touch ⓀK.

● A check mark appears on the selected video.
  To remove the check mark, touch ⓀK.
● Touch "CHECK" to check the video.

6 After selecting, touch "SAVE".

7 Select "EXECUTE" and touch ⓀK.

● The number of discs required to copy the files is displayed. Prepare the discs accordingly.
● Touch "CHECK" to check the file to copy.

8 Select "YES" or "NO" and touch ⓀK. (🎥 mode only)

● When "YES" is selected, videos with similar recording dates are displayed in groups.
● When "NO" is selected, videos are displayed according to recording dates.

9 Select "EXECUTE" and touch ⓀK.

● When "INSERT NEXT DISC" appears, change the disc.

10 After copying, touch ⓀK.

11 Close the LCD monitor, then disconnect the USB cable.

CAUTION:
● Do not turn off the power or remove the USB cable until copying is complete.
● Files that are not on the index screen during playback cannot be copied.

Memo:
● To check the created disc, select "PLAYBACK" in step 1.

When "DO YOU WANT TO FINALIZE?" appears

This appears when "AUTO FINALIZE" in the camera settings menu is set to "OFF".

- To play back on other devices, select "YES" and touch ⊛.
- To add more files to the DVD later, select "NO" and touch ⊛.

Memo:

- When two or more DVDs are created simultaneously, all the discs other than the last one will be finalized automatically even when "AUTO FINALIZE" is set to "OFF".
- You can finalize a DVD even when "FINALIZE" is selected in the "BACK-UP" menu.
- To play back a BD-R disc on other devices, select "FINALIZE" after creating the disc.
  (The "AUTO FINALIZE" function on the camera settings menu can only be used for creating DVDs.)