

Recording Menu (Still Image)

You can adjust various settings, such as brightness and white balance, to suit the subject or purpose. You can also change settings such as picture quality and gain.

Setting	Details
MANUAL SETTING	Recording settings can be adjusted manually. • They are displayed only when recording in the manual mode.
FACE PRIORITY AE/AF	Detects faces and adjusts the brightness and focus automatically.
FLASH	For setting the flash.
SELF-TIMER	Use this when taking a group photo.
SHUTTER MODE	Continuous shooting settings can be adjusted.
IMAGE SIZE	Sets the image size (number of pixels) for still images.
IMAGE QUALITY	Sets the image quality.
GAIN UP	Makes the subject appear bright automatically when recording in dark places.
AUTO REC	Enables the unit to record still images automatically by sensing the changes in brightness within the red frame displayed on the LCD monitor.