

---

**The recorded subject is too dark.**

Use backlight compensation when the background is bright and the subject is dark.

Use "LIGHT" or "FLASH" in the menu.

Use "NIGHT EYE" in SCENE SELECT.

Use "GAIN UP" in the menu.

Set "BRIGHTNESS ADJUST" in the manual settings menu to the "+" side.