


Formatting the USB External Hard Disk Drive

All files on the external hard disk drive can be deleted.

CAUTION:

- All data on the external hard disk drive will be deleted when it is formatted.
Copy all files on the card to a PC before formatting.

- 1 Select video or still image mode.



- 2 Select "FORMAT" and touch **OK**.



- 3 Select "YES" and touch **OK**.



- After formatting, touch **OK**.