

Short usage time even after charging.

Battery deterioration occurs when a battery pack is charged repeatedly.
Replace the battery pack with a new one.