

## MONITOR BRIGHTNESS


Sets the brightness of the LCD monitor.

| Setting | Details   |
|---------|---|
| 4       | Brightens the backlight of the monitor regardless of the surrounding conditions.            |
| 3       | Sets to the standard brightness.  |
| 2       | Darkens the backlight of the monitor regardless of the surrounding conditions.              |
| 1       | Sets to dim brightness.<br>Helps to save battery life when selected.                        |
| AUTO    | Sets the brightness automatically to "4" when using outdoors and to "3" when using indoors. |


### Displaying the Item

**Memo :** \_\_\_\_\_


To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.



1 Press MENU.



2 Select "DISPLAY SETTINGS" and press OK.



3 Select "MONITOR BRIGHTNESS" and press OK.

