

Playback Menu (Video)

You can delete or look for specific videos.

Setting	Details
DELETE	Deletes unwanted videos.
PROTECT/CANCEL	Protects files from being deleted accidentally.
COPY	Copies files to another media.
MOVE	Moves files to another media.
SEARCH DATE	Refines the index screen of videos according to recording date.
PLAYBACK OTHER FILE	Plays videos with defective management information.
SEAMLESS REC CTRL	Videos that are recorded on two separate media and with "SEAMLESS RECORDING" in the video recording menu enabled can be combined into a single video.
CLOCK ADJUST	Resets the current time or sets to the local time when using this unit overseas.
REC MEDIA SETTING	Sets the recording/playback media of videos.
ON-SCREEN DISPLAY	Sets whether to show on-screen displays such as icons during playback.