

Deleting Unwanted Files

Delete unwanted videos when the space in the recording media is running out.

The capacity of the recording media can be restored after deleting the files.

Memo :

- Deleted files cannot be restored.
- Files that are protected cannot be deleted.
Release protection before deleting the file.
- Be sure to back up important files on a computer.

Deleting a Video with Defective Management Information

Videos with defective management information cannot be deleted with the "Deleting the Currently Displayed File" function. This deletion is also not possible on the index screen.

■ To delete a video with defective management information

- 1 Start or pause playback of a file.
- 2 Press MENU.
- 3 Select "DELETE" and press OK.
 - "CURRENT" cannot be selected.