

Media Settings Menu

You can perform various settings for the recording media.

Setting	Details
FORMAT SD CARD	Deletes all files on the SD card.
FORMAT BUILT-IN MEM.	Deletes all files on the built-in memory.
ERASE ALL DATA	Execute this process when disposing of this unit or passing it to another person.