

**Images do not appear on the TV properly.**

Disconnect the cable and connect again.  
Turn off and on this unit again.