

Carga de la batería en el extranjero

La forma del tomacorriente varía según el país y la región.
Para cargar la batería, necesita un enchufe adaptador que coincida con la forma del tomacorriente.

A	B	BF	C	O
				

North America	Europe	Oceania	Middle East
United States A	Iceland C	Australia O	Israel C
Canada A	Ireland C	Guam A	Iran C
Mexico A	United Kingdom B BF	Tahiti C	Kuwait B C
	Italy C	Tonga O	Jordan B BF
Asia	Austria C	New Zealand O	
India B C BF	Netherlands C	Fiji O	Africa
Indonesia C	Canary Islands C	Latin	Algeria A B BF C
Singapore B BF	Greece C	Argentina O	Egypt B BF C
Sri Lanka B C BF	Switzerland C	Colombia A	Guinea C
Thailand A BF C	Sweden C	Jamaica A	Kenya B C
South Korea A C	Spain A C	Chile B C	Zambia B BF
China A B BF C O	Denmark C	Haiti A	Tanzania B BF
Japan A	Germany C	Panama A	Republic of South Africa B C BF
Nepal C	Norway C	Bahamas A	Mozambique C
Pakistan B C	Hungary C	Puerto Rico A	Morocco C
Bangladesh C	Finland C	Brazil A C	
Philippines A BF O	France C	Venezuela A	
Vietnam A C	Belgium C	Peru A C	
Hong Kong Special	Poland B C		
Administrative Region B BF	Portugal B C		
Macau Special	Romania C		
Administrative Region B C			
Malaysia B BF C			