

**Short usage time even after charging.**

Battery deterioration occurs when a battery pack is charged repeatedly.  
Replace the battery pack with a new one.